



**ELENCO PEZZI DI RICAMBIO
 LISTE PIECES DETACHEES
 SPARE PARTS LIST
 ERSATZTEILLISTE
 PIEZAS DE REPUESTO**

ENERGY 1500 START



Esplodo macchina, Dessin appareil, Machine drawing, Explosions Zeichnung des Geräts, Diseño seccionado maquina.



REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	CODE CODICE KODE	REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	CODE CODICE KODE	REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	CODE CODICE KODE	REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	CODE CODICE KODE
1	Temporizzatore Timer Timer Timer Timer	112120	12	Comando A Distanza Commande A Distance Remote Control Fernsteuerung Comando De Distancia	123993	23	Ruota Fissa Roue Fixe Fixed Wheel Fixes Rad Rueda Firme	322200	34	Pinza Di Massa Pince De Masse Work Clamp Masseklemme Pinza De Masa	712102
2	Raddrizzatore Redresseur Rectifier Gleichrichter Rectificador	112390	13	Cavo Alim. Cable Alim. Mains Cable Netzkabel Cable Alim.	132166	24	Piedino Embout Foot Fuss Pie	644296	35	Cavo 50mm ² 3m E Pinza Positivo Cable 50mm ² 3m Et Pince Positive Kabel 50mm ² 3m Und Positive Zange Cable 50mm ² 3m Y Pinza Positivo	713162
3	Basetta Cambio Tensione Platine Pour Change Tension Changing Voltage Card Wechselspannungskarte Base Cambio Tension	112163	14	Shunt Per Amperometro Shunt Pour Amperemetre Shunt For Ammeter Shunt Fuer Amperemeter Shunt Para Amperometro	152040	25	Manico Poignee Handle Handgriff Manija	644579	36	Cavo 50mm ² 3m E Pinza Di Massa Cable 50mm ² 3m Et Pince De Masse Kabel 50mm ² 3m Und Work Clamp Kabel 50mm ² 3m Und Massezange Cable 50mm ² 3m Y Pinza De Masa	713163
4	Manopola Per Temporizzatore Poignee Pour Timer Knob For Timer Griff Fuer Timer Manija Para Timer	112296	15	Ventola Helice Fan Blade Fluegelrad Aventador	152054	26	Cruscotto Tableau Dashboard Schaltbrett Cuadro	649232	37	Fusibile Fusible Fuse Sicherung Fusible	122432
5	Manopola Per Commutatore Poignee Pour Commutateur Switch Knob Schaltergriff Manija Por Conmutador	322901	16	Motore Ventilatore Moteur Ventilateur Fan Motor Ventilatoromotor Motor Ventilacion	152110	27	Retro Partie Arriere Back Panel Rueckseite Trasera	650365	38	Volantino Per Morsetto Volant Pour Borne Knob For Clamp Handrad Fuer Klemme Volante Por Borne	312024
6	Deviatore Gareur Switch Schalter Interruptor	122400	17	Mascherina Amperometro Couvercle Amperemetre Ammeter Cover Amperemetersdeckel Cubre Amperimetre	152087	28	Fianco Destro Partie Laterale Droite Right Side Panel Rechte Seite Flanco Derecho	650487	39	Kit Morsetto Pinza-massa Kit Borne Pince-masse Kit Terminal Clamp-earth Kit Klemme Zange-masse Kit Terminal Pinza-masa	990057
7	Commutatore Commutateur Switch Schalter Conmutador	122489	18	Amperometro Amperemetre Ammeter Amperemeter Amperometre	152098	29	Fianco Sinistro Partie Laterale Gauche Left Side Linke Seite Flanco Izquierdo	650488	40	Kit Coppia Rondelle Isolanti Kit Rondelles Isolantes Insulating Washers Kit Isolierscheibekit Kit Arandelas Asladoras	990163
8	Commutatore Commutateur Switch Schalter Conmutador	122490	19	Trasformatore Ausiliario Transformateur Auxiliaire Auxiliary Transformer Hilfstransformator Transformador Ausiliario	164270	30	Frontale Partie Frontal Front Panel Gerätefront Frontal	655191	41	Protezione Raddrizzatore Protection Redresseur Rectifier Protection Gleichrichterschutz Protector Rectificador	112182
9	Kit 10 Fusibili Kit 10 Fusibles Kit 10 Sicherungen Kit 10 Fusibles	802129	20	Trasformatore Transformateur Transformer Transformator Transformador	164699	31	Mascherina Coprifusibile Masque Fusible Fuse Cover Sicherungsschutz Mascara Fusible	655621	42	Termostato Thermostat Thermostat Thermostat Thermostat	122132
10	Teleruttore Telerupteur Contactor Fernschalter Contactor	122585	21	Pressacavo Presse Cable Cable Bushing Kabelhalter Prensa Cable	312068	32	Asse Per Ruote Axes Pour Roue Wheels Axle Raederachse Eje Por Rueda	681139	43	Termostato Thermostat Thermostat Thermostat Thermostat	122796
11	Interruttore Interrupteur Switch Schalter Interruptor	122725	22	Pressacavo Presse Cable Cable Bushing Kabelhalter Prensa Cable	322112	33	Pinza Di Massa Pince De Masse Work Clamp Masseklemme Pinza De Masa	712101	44	Morsetto Per Fusibile Borne Pour Fusible Fuse Holder Clamp Sicherungshalter Klemme Bocadillo Para Fusible	980037

Schema elettrico, Schéma électrique, Diagram, Schaltplan, Esquema de conexiones.

